

Instructions for Single Hung Swinging Doors

STEP 1: Frame rough opening 1 ½" more than door height. 1 ¾" more than door width.

STEP 2: Put door frame header and 2 sides together and put in rough opening making sure header is level, put #12 x 1 Tex screw in each corner after doors are in position put #12 x 1 Tex screw every 18".

STEP 3: Make sure side frames are plumb and fasten with #12 x 1 Tex screw at each corner after doors are in position put #12 x 1 Tex screws every 18".

STEP 4: Mount doors with 1 #12 x 1 Tex screw in each hinge leave a ¼" gap between door and door frame after everything is square and doors are in position put 3 #12 x 1 Tex screws in each hinge.

STEP 5: Mount brushes on bottom and inside of door or 2" bottom door expander with weather seal. For brushes use #8 x ¾" Tex screws and #10 x ¾" screws for door expander, adjust to rub lightly against floor put brushes against lip of outer door frame to edge of door it may be necessary to cut a little bit of brushes.

STEP 6: Mount chain stops on inside of doors fasten one end to the door with 2 #14 x 1 Tex screws and other end to rough opening frame with 2 #12 x 1 Tex screws, it may be necessary to screw block or angle on rough opening frame to make it even with the bottom of the door frame so chain doesn't rub against frame

STEP 7: Mount latch with keyed lock on top side of handle

STEP 8: Screw #12 x 1 Tex screw through frame into angle to hold header frame and side frame together.